


by DICA

All slings, especially synthetic slings, can be damaged when lifting a load if they are not properly protected. Edge protection with sling use is critical in preventing a sling failure, and is a requirement in current sling safety standards. Cut and damaged slings are the leading cause of most rigging related accidents.


"Slings in contact with edges, corners, or protrusions should be protected with a material of sufficient strength, thickness, and construction to prevent damage to the sling" (ANSI/ASME B30.9-1.10.4)

"Slings shall be padded or protected from the sharp edges of their loads" **OSHA 29CFR1910.184(c)(8)**










LiftGuard™ Magnetic Sling Protectors are only 1/7th the weight of steel, no tools are needed since magnets allow for quick and easy attachment and removal.






Corner protectors in use



12,500 lbs per inch of web sling width only with FULL contact on inside surfaces


Visit dicausa.com/downloads for product warnings and guidelines.






MEDIUM DUTY

Width	Part #
6"	LG-6-3-90
9"	LG-9-3-90
12"	LG-12-3-90
18"	LG-18-3-90








HEAVY DUTY

Width	Part #
6"	LG-6-3-270
9"	LG-9-3-270
12"	LG-12-3-270
18"	LG-18-3-270



GROOVED

Width	Part #
9"	LG-9-2-360G-0.5
12"	LG-12-2-360G-0.5
18"	LG-18-2-360G-0.5

other sizes can be manufactured on request

Visit dicausa.com/downloads for product warnings and guidelines.

